No more traditional paint strippers, thanks to the EEC!! Don't settle for second best performance!

Don't put yourself and your customers at risk with hazardous alternatives!



THERMOSTRIP PRO is a water based, low odour gel for professional & DIY

Strips Paint, Varnish, Artex[®] , Stains and Lacquers

Removes ALL graffiti

From Wood, Metal, Brick, Stone & Fibreglass

Even removes carpet adhesive residues from floors

Internal or external

Water-borne and non-flammable

Non-corrosive, non-ozone depleting

Safe to handle and store Widely adopted by professional stripping

There is no SAFER, more EFFECTIVE stripper on the UK market - Call your normal Thermoguard contact for more information

You Tube - Search for 'Thermostrip

THERMOGUARD UK Ltd 147 Gibraltar Street Sheffield S3 8UA TELEPHONE 0114 2768008 Option 1 Orders Option 2 Technical, Sales Enquiries and Prices Option 3 Accounts



www.thermoguarduk.com





THERMOSTRIP from THERMOGUARD

INSTRUCTIONS

What can it be used for?

External:

- Widely used for Buildings Boats Railings Graffiti
- Wood stains Decking etc.

Internal:

- Doors & Panelling Staircases Walls Ceilings
- Floors Artex[®] Graffiti

How long does it take?

Temperature affects the speed of strip - **the warmer the better**. (Less effective under 10°C - ideal working temperature 25°C)

Varnish: 20 - 60 minutes

Paint: 20 - 60 minutes

Two pack varnish: 40 - 90 minutes

Heavy multi layered paint: 90 minutes - overnight

Two pack lacquer: 60 minutes - 4 hours

Always test a small area before use. Multiple layers may need a second coat .

Always read Health and Safety Data before use.

If leaving overnight cover with plastic to help the stripping process. (Not essential but useful for tough thick coatings)

How to use:

- 1. Cover top with a cloth during opening to avoid splashes.
- Apply a generous, even coat do not brush out. Layer Thermostrip onto surface to be stripped with a suitable clean brush.
- Leave for approx 2 hours and apply a second generous coat. On less than 5 layers of paint or varnish a second coat may not be necessary.

- 4. After product has penetrated the substrate (up to 24 hours) scrape off with suitable scrapers, leaving surface as clean as possible,
- Remove residues with cold water and a stainless steel scourer (NEVER WIRE WOOL) and leave to dry.
- **6.** For surfaces requiring a perfect finish, rinse with 'Thermowash' to remove all residues.

In certain circumstances it may be easier to remove first coating of Thermostrip Pro with scrapers and reapply if surface coating is delaminating.

It may be possible to enhance the performance of Thermostrip by leaving the product for longer periods or in some circumstances overnight on extremely difficult coatings, ensuring the product is well coated and covered with plastic to avoid drying out.

Preparation:

Ensure surfaces to be stripped are dry. Always protect adjacent floors and delicate surfaces.

Tips that the trade use:

- Always apply a thick generous coat.
- Do not spread the product too far. (this may result in poor penetration)
- Always let Thermostrip do the work for you. The longer you leave it the more it will strip.
- Never let the product dry out.

NOTE: THERMOSTRIP PRO WORKS QUITE DIFFERENTLY FROM TRADITITIONAL STRIPPERS. IT NEEDS TO BE LEFT IN PLACE AND WORKS FROM THE BOTTOM UP, THUS OFTEN AVOIDING REPEATED SCRAPING AND REAPPLICATION. IT IS THEREFORE VERY ECONOMICAL IN APPLICATION, BUT REQUIRES A CHANGE IN TECHNIQUE.

You Tube - Search for 'Thermostrip Pro'



THERMOGUARD UK Ltd 147 Gibraltar Street Sheffield S3 8UA TELEPHONE 0114 2768008 Option 1 Orders Option 2 Technical, Sales Enquiries and Prices Option 3 Accounts